

16
P
I
N
T
O
B
O
A
T

- A -MAIN POWER RED
- B-J1-33 V5BB_PP1 WHITE
- C-J1-47 PPS1 DK BLUE
- D-J1-36 RTN_PP1 BLACK
- E-J1-35 V5BA_PP2 RED
- F-J1-49 PPS2 GREEN
- G-J1-37 RTN_PP2 ORANGE
- H-GROUND BLACK
- J-IGNITION YEL/BLK
- K-START YEL/RED
- L-BUZZER TAN/BLU
- M-MIL LAMP PINK
- N-CAN HIGH GREEN
- P-CAN LOW YELLOW
- R-ANALOG TACH GRAY
- S-IGNITION PURPLE

CAN
BUSS
DATA
LINK

- A-IGNITION ORANGE
- B-GROUND BLACK
- C-CAN HIGH GREEN
- D-CAN LOW YEL

TRIDUCER-
VESSEL
SPEED
SENSOR

- A-CAN LOW YELLOW
- B-CAN HIGH GREEN
- C-GROUND BLACK
- D-IGNITION YEL/BLK
- E-J3-64 VSSD GRN/WHT

**MEFI 5A
ENGINE**

FUEL
SENDER

- A-J1-44 FL LVL SENSOR WHT
- B-GROUND BLACK

HIGH
PRESSURE
PUMP

- 1-RED FUEL PUMP RELAY +
- 2-BLACK GROUND

LOW
PRESSURE
PUMP

- RED- FUEL PUMP RELAY +
- BLACK- GROUND

RED J1-1
ECM POWER
CONNECT DIRECTLY
TO BATTERY SWITCH
USE 10 AMP FUSE

